



Quick Cleaning Process

1. Push two patches soaked with Montana Xtreme Copper Killer thru bore
2. Soak bronze brush with Montana Xtreme Copper Killer – Stroke bore ten times. Re-saturate Brush with solvent- stoke another 10 times.
3. Let it sit 5 minutes
4. Two dry patches thru bore
5. Spray out muzzle brake with 91% Alcohol
6. Swab out chamber with dry 3” patch on loop style jag
7. Swab out chamber with lightly alcohol soaked 3” patch on loop jag
8. Two patches soaked with alcohol thru bore
9. Two dry patches thru bore
10. Swab out chamber with 3” dry patch
11. Two patches soaked with Montana Extreme Bore Condition Thru bore
12. Two dry patches thru bore
13. Swab out chamber with 3” dry patch
14. Swab action lug recesses and raceway
15. Lightly relube action raceway
16. Wipe off bolt
17. Grease bolt lugs and lightly relube bolt body